

# FASTLAY FAMILY

Install your LVT Dryback floor as a floating floor with the revolutionary Multiprotect LVT Fastlay assembly mat. You don't have to be an experienced glued-floor fitter (even laminate-floor fitters will manage Dryback installation with ease).



Underlay ideal for Dryback floors. It can be used for quick renovation without interference in subsoil.

Minimum subsoil preparation (eliminates minor unevenness) and much quicker glue assembly. Innovative self-adhesive layer allows corrections up to 30 minutes after floor installation.



The surface of the mat is covered with an acrylic emulsion adhesive, reinforced with polyester mesh.

Such adhesives have HIGH INITIAL ADHESION properties, which means that powerful bonds are created within just 30 minutes, after which the floor can be used safely.

Floors installed with Fastlay can be used almost immediately after installation (the initial bonding time for the adhesive is 30 minutes).

If any mistakes are made, it is recommended that the placement of the panel be changed within 10 minutes from the moment of first contact with the mat.





### MULTIPROTEC LVT FASTLAY HD

### SECURA LVT FASTLAY SMART

Material	PUM/PET	XPS
Thickness	1,8 mm	1,0 mm
Form	Roll	Smart
	6 m x 1 m / 6 m <sup>2</sup>	5,30 m x 1,18 m / 6,25 m <sup>2</sup>
	-	-
	240 m <sup>2</sup>	262,5 m <sup>2</sup>
	yes	yes
	up to 0,01 m <sup>2</sup> K/W	up to 0,03 m <sup>2</sup> K/W
	up to 17 dB	up to 17 dB
	up to 500 kPa	up to 400 kPa
	up to 0,6 mm	up to 0,5 mm
	75	75

EAN 5905167816967

EAN 5905167803547

